



DAILY SAFETY CHECK



For Your Customers' Safety and for Your Own Protection
Perform This Safety Check DAILY on Each

AUTOMATIC SLIDING DOOR

These minimum safety checks, in addition to those in the owner's manual, should be made each day and after any loss of electrical power:

1. Walk toward the door at a normal pace. The door should open before you reach the threshold.
2. Stand motionless in threshold for at least 10 seconds. The door should not close.
3. Inspect the threshold area. It should be clean with no loose parts that might trip or cause user to fall. Keep traffic path clear.
4. Move clear of the area. The door should remain open for at least 1.5 seconds and should close slowly and smoothly.
5. Inspect the glass and safety decals. All should be present and in good condition.
6. Repeat steps 1 through 5 from other direction if door is used for two-way traffic.
7. Have door inspected by an AAADM certified inspector at least annually or after any adjustments or repairs.
8. **DO NOT USE DOOR** if it fails any of these safety checks or if it malfunctions in any way. Call a qualified automatic door service company to have door repaired or serviced.
9. See owner's manual or instructions for details on each of these and other safety items. If you need a copy of the manual, contact:

FOR SERVICE CALL

800-966-OPEN (6736)

www.automated-entrance.com

AUTOMATED ENTRANCE SYSTEMS CO., INC.

313 ARCHIE STREET • OAKMONT, PENNSYLVANIA 15139-1906

(AAADM certified inspectors on staff)